

MIXED MACHINE ADDENDUM

BEFORE CONNECTING THE ULTRAFILLER MACHINE TO A SOCKET ENSURE THAT:

- 1) THE MACHINERY HAS NOT BEEN DAMAGED DURING TRANSPORT;
- 2) ALL HOSES ARE CONNECTED TO THE MACHINERY AND HAVE NOT BEEN DAMAGED DURING TRANSPORT;
- 3) THE TANK CAP IS CORRECTLY INSERTED;
- 4) THE DRAIN TAP ON THE TANK IS COMPLETELY CLOSED.

CONNECT THE MACHINE TO YOUR POWER SOCKET (**AFTER CHECKING THAT THE VOLTAGE OF YOUR SYSTEM CORRESPONDS TO THE DATA ON THE MACHINE PLATE**), THEN TURN ON THE MACHINE ULTRAFILLER.

WHEN THE MACHINE IS ON:

- 1) **THE VACUUM INDICATOR BEGINS TO RISE IN VALUE:**
 - WAIT FOR THE VALUE TO STABILIZE, THEN FLUSH WITH WATER TO REMOVE ANY DUST RESIDUES AND CHECK THE CORRECT OPERATION OF THE MACHINE.
 - **N.B. IN ORDER TO REDUCE DRAUGHT TIMES AT START-UP, IT IS NECESSARY TO USE THE STANDARD SPOUTS FOR THE FIRST DRAUGHT AND SUBSEQUENTLY TO USE THE MIGNON SPOUTS.**
- 2) **THE VACUUM INDICATOR DOES NOT BEGIN TO RISE IN VALUE:**
 - ENSURE THAT THE VACUUM ADJUSTMENT VALVE IS ON THE MAXIMUM VALUE OR COMPLETELY ROTATED CLOCKWISE.
 - **APPLY A PUSH FOR A FEW SECONDS ON THE REMOVABLE TANK COVER.** WHEN THE INDICATOR BEGINS TO RISE, WAIT FOR IT TO STABILIZE, THEN PERFORM THE REQUIRED FLUSHES.
 - **N.B. IN ORDER TO REDUCE DRAUGHT TIMES AT START-UP, IT IS NECESSARY TO USE THE STANDARD SPOUTS FOR THE FIRST DRAUGHT AND SUBSEQUENTLY TO USE THE MIGNON SPOUTS.**

N.B. IT IS IMPORTANT TO CLEAN AND SANITIZE BEFORE AND AFTER USE. IT IS POSSIBLE TO DO THIS WITH WARM WATER IN ORDER TO REMOVE ANY RESIDUES OF SUGARS WHICH MAY OBSTRUCT THE INTAKE CHANNELS. THE POT CAN BE WASHED SIMPLY WITH WATER OR WITH DETERGENT IF THE MACHINE IS USED WITH OIL OR OTHER GREASE/SUGAR.

